

COR: new chart (WEF xxxxxxxxxx)

COMMUNICATION FAILURE PROCEDURE:

- Set transponder on code 7600.
 - Cross PRRPP, GERSA, VEBIT climbing to/at last received and acknowledged FL but not below MCA*.
 - Continue climb to FPLFL.
- *) Leave last received and acknowledged FL or ALT earliest three minutes after airborne